

Beckers



ScotteTak

ScotteTak is a completely flat, water-based co-polymer paint with excellent hiding properties for covering new unfinished ceilings indoors, or previously painted interior ceilings. If the ceiling has a sand-spackled surface that is very coarse and grainy, we recommend using Scotte Lätt Tak instead.

ScotteTak is suited for application on most types of ceiling materials, such as plaster, concrete and sand-spackled surfaces, as well as fibreboard, plasterboard and previously painted surfaces.

ScotteTak has virtually no odour during painting and drying. The paint does not yellow with age. ScotteTak creates a completely flat, mottle-free surface with low grain. ScotteTak dries quickly and has excellent hiding properties.

ScotteTak is marked with the EU flower, the eco-label of the European Union for environmentally safe paints. ScotteTak is also recommended by the Swedish Asthma and Allergy Association.



TECHNICAL DATA

BINDER	Co-polymer latex.
THINNING	Use water, although the paint is normally not thinned.
COVERAGE	6-8m ² /litre.
TOOLS	Use a roller, spray gun or paintbrush.
CLEANING OF TOOLS	Use water.
TIME TO RECOAT	Wait about 3 hours at a temperature of +23°C and 50% relative humidity.
DRYING TIME	Tack-free after about 30 minutes at a temperature of +23°C and 50% relative humidity.
GLOSS	Completely flat, about 2 gloss units.
COLOUR RANGE	White.
FLAMMABILITY	Non-flammable.
STORAGE	Store above freezing.

NEW UNFINISHED SURFACES

Preparing the surface: Clean the surface to remove dust, dirt and loose particles, then prime it with Scotte Grund or Scotte Tak.

Spackling, filling and patching: Use Breplasta or Beckers Väggspackel to spackle over joints, nail holes and other uneven areas. Sand afterwards with medium-fine sandpaper.

Painting: Apply one or two finish coats of Scotte Tak.

PREVIOUSLY PAINTED SURFACES

Preparing the surface

Previously painted surfaces: Wash with Beckers Målartvätt liquid degreaser and cleaner. Wash thoroughly with water afterwards. Between coats, dull any shiny surfaces with medium-fine sandpaper to provide the best possible adhesion.

Surfaces painted with distemper: Wash off the distemper with water. If you cannot remove all of the distemper, we recommend that you prime the surface with Grepp Grundfärg or Scotte Isolergrund before applying the finish coat.

Lime-washed surfaces: Scrape and brush the surface until it is sound and has no loose particles. Dust the surface or wash it with water. Prime with Grepp Grundfärg.

Surfaces stained by nicotine or damaged by water: When painting over these surfaces with Scotte Tak, stained or discoloured areas can migrate through the paint. This can be avoided by sealing and covering the stain or discoloured areas first with Scotte Patentfärg and then applying a finish coat of Scotte Tak, or a coat of Nondrop paint.

Spackling, filling and patching: Use Beckers Spackel or Breplasta spackle.

Painting: Apply one or two finish coats of Scotte Tak.

Application: A roller or paintbrush is normally used. Apply a generous amount of Scotte Tak using irregular rolling movements in order to avoid lines between rolled areas. The paint can also be applied with high-pressure spray equipment.

Cleaning: Tools are cleaned with water immediately after use. Wipe away as much paint as possible from tools before you clean them in water as this will reduce the load on your local sewage treatment plant. Seal open cans tightly. Do not pour liquid waste down the drain take it to a local environmental station for disposal. Hand in empty cans for recycling at an authorized facility.

CAUTION: Do not paint on surfaces colder than +5°C.