

Beckers



Elegant Aqua Lackfärg Blank

Elegant Aqua Lackfärg Blank is a water soluble, acrylic latex based paint intended for painting of interior woodwork.

Elegant Aqua Lackfärg is designed for use on all types of interior woodwork, both new and previously painted surfaces.

Elegant Aqua Lackfärg has a very low odour during painting and drying. It is easy to apply with excellent hiding and leveling abilities and is able to adhere to surfaces previously painted with oil or alkyd paint. Nonyellowing. There are also considerably less thermoplastics so it can even be used in storage areas.



TECHNICAL DATA

BINDER	Acrylic latex.
SOLVENT	Water.
THINNING	Water.
COVERAGE	8-10 m ² /litre.
TOOLS	Brush, roller or spray gun.
CLEANING OF TOOLS	Use water.
TIME TO RECOAT	Wait about 8 hours at a temperature of 23°C and 50% humidity.
DRYING TIME	Tack-free after 4 hours at a temperature of 23°C and 50% humidity.
GLOSS	Abot 70 gloss units.
COLOUR RANGE	White, can be tinted in the Beckers Colour System.
FLAMMABILITY	Non-flammable.
STORAGE	Store above freezing.

Elegant Aqua Lackfärg Blank

SURFACE PREPARATION

Unpainted wood, joinery, etc: Brush away dirt and loose particles. As a base coat use Beckers Snickerislip. Apply 1 to 2 coats Aqua Snickerilack.

Previously painted surfaces: To apply Aqua Snickerilack to surfaces painted with oil or alkyd based paint, first wash surface with Tarväck Målartvätt and rinse thoroughly with water, sand and surface.

Factory painted woodwork: Clean surface with Tarväck Målartvätt and rinse thoroughly with water.

Finishing: Apply 1 or 2 coats Aqua Snickerilack.

Note: Do not paint if surface temperature is below +8°C.

Thinning: Under normal conditions unnecessary. The paint is soluble in water.

Cleaning: Clean brush or other applicator with water as soon as possible.

Application: Brush, roller or spray gun.

Beckers

